

Service-Tool for parameterisable and communicative Belimo actuators /VAV controllers and HVAC performance devices.

Connection via service socket on the device or MP/PP connection.

ZIP-USB function



## Technical data

<b>Electrical data</b>	Power supply	AC 24 V, 50/60 Hz, DC 24 V (from actuator)
	Operating range	AC 19,2 ... 28,8 V / DC 21,6 ... 28,8 V
	Power consumption Operation	1 W
<b>Connection</b>	Socket for connecting cable ZK	ZK1-GEN (5m) supplied with connector
	USB 2.0 Interface	USB socket Type B, connecting cable (1 m) with socket A to B supplied
	Optional cables	ZK2-GEN, ZK6-GEN
<b>Interface</b>	Communication	Point to Point (PP), no Bus mode possible (MP)
<b>Operating modes</b>	Parameterization	Point to Point connection Connection using Service socket on the actuator or terminals
	MP-level converter ( ZIP-Function)	Connection on the cabinet or over service socket on the actuator
		MP-Monitor operation, connection on the MP-Bus
<b>Operating</b>	LCD-display	2 x 16 characters, with background illumination
	Keys	i / esc / ▼ / ▲ / OK
<b>Safety</b>	Protection class	III Safety extra-low voltage
	Electromagnetic compatibility	CE in accordance with 2004/108/EG
	Operating temperature	0 ... 50 °C, non-condensing
	Non-operating temperature	-20 ... 50 °C, not-condensing
<b>Dimensions / Weight</b>	Dimensions	L x W x D: 95 x 55 x 25 mm
	Weight	Approx. 135 g

## Definitions

<b>ZTH AP</b>	The ZTH is sold worldwide. Therefore the product name for the Asia region is defined as ZTH AP. On the product information, the expression ZTH is representative for the ZTH AP.
<b>Actuators</b>	For simplicity ,In this documentation the terms actuators, VAV-Controller, fire damper actuators and HVAC performance devices are summarized by the term actuators.

## Supported devices

<b>Damper product range</b>	..-MF / ..-MP / ..-MPL / ..-MFT(2) / ..-MOD / ..LON	
<b>Valve product range</b>	..-MF / ..-MP / ..-MPL / ..-MFT(2) / ..-MOD / ..LON	
<b>EPIV – pressure-independent characterised control valve</b>	P6..W..-MP (EU) / EPIV-xx-xxx (AP)	Available starting 2011
<b>Fire damper actuator B</b>	BF-Top Line with BKN230-24MP	
<b>VAV product range</b>	VRD2 / VRD2-L	available 1992-2007
	VRD3	available starting 2008
	VRP-M (VAV- und STP-applications)	available starting 2005
	NMV-D2..	available 1992 to 2000
	LMV-D2M / NMV-D2M	available 2000 to 2006
	LMV-D2-MP / NMV-D2-MP / SMV-D2-MP.., LHV-D2-MP..	available 2006 to 2011
	LMV-D2LON / NMV-D2LON	available 2006 to 2011
	LMV-D3-MP / NMV-D3-MP / SMV-D3-MP.., LHV-D3-MP..	available starting 2011
	LMV-D3LON / NMV-D3LON	available starting 2011
	LMV-D3-MOD / NMV-D3-MOD	available starting 2012
<b>HVAC performance devices</b>	According to system description ( e.g. Energy Valve)	
<b>sharedlogic</b>	According to system description	

## Safety Notes



- The device is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport..
- Connection allowed only to Belimo-devices with 24 V- safety extra-low voltage and PP/MP-interface.
- Changes of parameters, etc. may not be performed except after consultation/specification of the OEM, device or mechanical/electrical contractor. Operating and adjustment regulations must be observed.

## Connection ZTH AP

### Connection and power supply

The ZTH's power is supplied via the actuator. The connection is set up

- directly at the Service socket of the actuator or
- via the PP/MP connection (U5) e.g. connection socket, in the control cabinet, room controller CR24

### Types of connection and connection cables



Suitable cable  
ZK1-GEN



Suitable cable  
ZK2-GEN





Suitable cable  
ZK4-GEN



Suitable cable  
ZK6-GEN

### Connection in the MP-Bus system




Direct connection to the MP bus or MP master is not possible with the ZTH-GEN.

Solution: Use the service socket on the actuator or temporarily disconnect the MP-connection of the MP-device from the MP-bus and connect the ZTH-GEN to the MP connection.

## Connection ZIP function


### Connection via the service socket

Local connection via the service socket cable ZK1-GEN




### Connection via connection cable

Local connection via ZK2-GEN




### PC-Tool as MP-Master

- to parameterize the actuators via MP-Bus
- set points for the simulation of actuators via the MP-Bus
- reading of the sensors that are connected to the MP-Bus
- recording of graphical trends



**Connection ZIP function****PC-Tool connection via ZK6 -GEN,  
ZK4-GEN on Belimo gateways**

For connection to the UK24MOD and UK24BAC the cable ZK6-GEN can be used  
For connection to the UK24EIB and UK24LON the cable ZK4-GEN can be used





## Connection ZIP-function

## PC-Tool as MP-Monitor

Check the MP-communication with the MP-Monitor tool (Module in PC-Tool V3.x)

C:\Program Files\Belimo\Belimo PC Tool V3.2\mp\_mon.exe

MP-MONITOR <V3.1>									
COM8 MODE3 D: disable BACKSPACE: clear ESC: exit									
Address	Series-No	Override	Stpt	Act_pos	Type	Act_vol	Unon	Designation	Position
Sensor	MM	State	Adapt/Sync/Test	Range	Min_Max	t_run	Direction		
MP1	00533-30012-142-128	NONE	79%	79%	LM24A-MP	95.1°		1.0G	B²ro 2
			7.9U	00000000				0x_100%	40s
MP2	00533-30009-142-128	NONE	79%	79%	LM24A-MP	95.3°			Inlet damper
			OFF	00000000				0x_100%	35s
MP3	00543-10271-142-143	CLOSE	8	0%		94.9°			CW
			0.3U					0x_100%	35s

PC-Tool Monitor connection  
ZK2-GEN on MP-MasterPC-Tool Monitor connection on tool  
socket with ZK6-GEN, ZK4-GEN

## Operating

When connecting the ZTH to the actuator, the control unit will start and read the data from the connected device.

The available settings and user options are displayed according to the device type.

The available configuration parameters are listed in the product information of all actuators.


### Operating elements

#### LCD display

- Background illumination
- Display 2 x 16 characters

#### Key function

- ▼ and ▲ Forward /backward Value / change Status
- OK Confirm entry, change to submenu
- ESC Abort entry, leave submenu, discard changes
- i shows additional information if available



RJ12 Connection socket

USB Connection socket

for PC communication

### Language setting, unit depiction

Language and units can be set in the Configuration menu.


### Operating

Operating is context-related, i.e. the user sees only the options available for the connected device.


The corresponding Configuration table is read from the actuator for this purpose. In addition to the parameter type, this table also contains the corresponding divisions, e.g.: minimally adjustable running time/type. Non-relevant options are not displayed.

### Menu structure, handling

The operating menu can be run through from both sides (▲▼ Keys).



### Change values



## Operating

### Starting / ending

The connection to the actuator is started by plugging in the RJ plug and terminated by unplugging it.

### Device specifications/Technical data

For a more detailed description, including setting parameters, we draw your attention to the respective separate product information. Check specific product documents.

## Configuration

### Start configuration

1. Press the key (OK) while simultaneously plugging in the connecting cable
2. Configuration menu display appears

### Configuration Menu


Option / Display	Setting	Product range	Explanation
Language	German / <b>English</b>	-	
Empty cache	Yes / <b>No</b>	-	Function to delete data profiles of HVAC actuators from the local cache
Backlight timeout	After 0..255 sec off / <b>always active</b>	-	Setting backlight duration in seconds
Show favourites	disabled/ <b>after 1...65535 s</b>	HVAC performance devices (Energy Valve)	Alternating display of the first 3 values after the set time
OEM-Number	0... <b>65535</b>	VAV	
Advanced Mode <sup>1)</sup>	Yes / <b>no</b>	VAV Fire damper Modbus	Enable settings: – VAV: Direction of rotation – VAV: set Vmin / Vmax to original values (call up OEM setting) – BF-Top: Adaption – Modbus: Base-Address
Expert Mode <sup>1)</sup>	Yes / <b>no</b>	VAV Valves	Enable settings: – VAV: Switching mode – VAV: Vmid parameter – VAV: Altitude compensation – Valves: Y characteristic curve
PICCV-Function	Yes / <b>no</b>	Valves	Belimo US Enable PICCV Wizard function
Measuring voltage supply	Value V (AC)	-	
Pressure unit	Pa / <b>inWC</b>	VAV	
Flow unit (Water)	m <sup>3</sup> /h / <b>l/min</b> / gpm	Valves	
Flow unit (Air)	<b>m<sup>3</sup>/h</b> / l/s / cfm	VAV	
Exit configuration	ESC		

Activate option <sup>1)</sup> only as needed and with the respective know-how; the adjustment of the respective parameters requires special expertise.




## Basic functions


**Device identification** The following menu tree shows the basic functions which are identical to all devices.



**MP-Address** In MP-capable actuators the MP-Address (PP, MP1-MP8) can be set.




**Modbus actuators** Modbus specific communication settings of an actuator with integrated Modbus interface (...MOD).



## Functions for damper / valve product range

The ZTH recognizes the device family of the connected device automatically  
The menu and the settings are shown related to the connected device.


**Menu tree** The following menu tree shows the possible settings and values of an LM24A-MP.



## Functions for globe valve product range


The ZTH recognizes the device family of the connected device automatically  
The menu and the settings are shown related to the connected device.

**Menu tree** The following menu tree shows the possible settings and values of an NVK24A-MP-TPC.



## Functions for EPIV – pressure-independent control valve

**Menu tree** The following menu tree shows the possible settings and values of an EPIV.



Possible settings with   in editing mode:

Auto, OPEN, CLOSE, Max, Stop

0.5 - 10V/2 - 10V/0.5 - 10V Y inv/2 - 10V Y inv


0...Vnom (U5 feedback signal will be adjusted simultaneously to V'max)

PP, MP1...MP8

(On MF types only PP)

## Functions for VAV-product range

**Menu tree** The following menu tree corresponds to the new VAV-Compact D3 generation:  
L/N/SMV-D3-MP, LHV-D3-MP, L/ NMV-D3LON , 1) L/MNV-D3-MOD



<b>Deviations</b>	<b>VRD2</b> (1992-2007)	Display actual value/setpoint in [% Vnom], Vmin in [% Vmax], Vmax in [% Vnom]	Read only	PP
	<b>VRD3</b> (starting 2008)	Display actual value/setpoint in [% Vnom], Vmin in [% Vnom], Vmax in [% Vnom]	HW potentiometer setting «Tool» → Read/write, otherwise → Read only	PP
	<b>VRP-M VAV</b>	up to V2.16 Vmin in [% Vmax], Vmax in [% Vnom] starting with V3.0 Vmin in [% Vnom], Vmax in [% Vnom]		PP / MP1...8
	<b>NMV-D2</b> (1992 – 2000) <b>NMV-D2M</b> (2000 – 2006)	Display actual value/setpoint in [% Vnom], Vmin in [% Vmax], Vmax in [% Vnom]		PP PP / MP1...8
	<b>Altitude compensation</b>	This function requires VAV-Compact D3 with firmware V2.06 (03/2013) or higher and ZTH with firmware V2.01 or higher		


**Information: VAV-Universal actuators**

The V-actuators L/N/SM24A-V, L/NMQ24A-SRV-ST, which fit the VAV universal controllers VR..., have a tool connection but are nevertheless not tool-capable!

1) Modbus settings, see previous description of " Basic functions for Modbus actuators"


## Functions for MPL-devices

**Menu tree** The following menu tree shows the possible settings and values of an MPL-actuator.



## Functions for fire dampers BF-TopLine

**Menu tree** The following menu tree shows the possible settings and values of a BF-TopLine actuator.



## ZIP Functions

In this configuration, the ZTH works as a level converter between the USB port of a PC and the Belimo MP device

The correct driver will be automatically installed on the PC when plugging the ZTH.

When the USB interface is connected, the ZTH switches to ZIP mode.

### Note:



If the ZTH is connected to the PC, the screen flashes a few times until the driver is installed on the PC.

#### ZIP Disabled

ZIP disabled

#### ZIP Master

ZIP Master



Tx:  Rx: 

Connection as MP master e.g. PC

If bus communication is present, this is indicated by flashing of Tx and Rx on the display.

#### ZIP Monitor

ZIP Monitor

Tx:  Rx: 

Connection at monitor function with the PC-Tool

If bus communication is present, this is indicated by flashing of Tx and Rx on the display.

## Checking the power supply

### Checking the power supply

The ZTH AP offers the possibility of checking the AC 24V power supply (III safety extra-low voltage) of the Belimo devices. Voltages >30V are not permitted!  
Application e.g. Commissioning, troubleshooting in the event of a malfunction.

#### Measurement procedure

Equipment: ZTH, ZK2-GEN

Connection:

- connect free wires of the ZK2-GEN to AC 24V.
  - white on GND (Connection 1 actuator)
  - blue on ~ (connection 2 actuator)
  - third wire (turquoise) do not connect
- Do not connect RJ12 plug to ZTH-GEN yet!

Start:

- Press the ZTH-GEN key (OK) while at the same time connecting the RJ12 plug
- Select Supply function with arrow key (▼)

End:

- Disconnect ZTH-GEN RJ12 plug or end Configuration function (ESC)

#### Display

Supply. okay  
AC 25V, VHW: 85%


Quality: okay: AC supply in the division 19.2 ... 28.8V

AC value: measured AC voltage (accuracy  $\pm 1.0V$  insofar as VHW >95%)

VHW: Relationship of positive to negative half-wave

The deviation of the positive half-wave value to the value of the negative half-wave may not be too large. As a rule: positive HW / negative HW x 100 should be >80%.

#### Explanation VHW



#### Possible problems

The following items influence the half-wave load:

- Transformer too small in its dimensions
- long signal cable length from transformer to VAV controller

## Firmware Upgrade

The ZTH AP can be updated using the ZTH updater to the latest firmware version.  
Please contact the nearest Belimo organisation for the required software and the instructions for the upgrade.

## Compatibilities

### Function and operation of the new ZTH

Actual information to:

- Firmware Upgrades
- Version overview, documentation

See [www.belimo.eu](http://www.belimo.eu)

The ZTH AP includes the functionality of all previous versions of the ZTH-GEN and ZTH-VAV

The hardware of the ZTH is not compatible with the hardware of the ZTH-GEN. The updates of the ZTH-GEN cannot be loaded to the ZTH

In addition, the new ZTH supports the ZIP-USB function. This can be used with for the ZTH EU updates and as well as level converter USB/MP for the PC-Tool

**ZEV** The ZEV Adjuster (1992 to 2007) is replaced by the ZTH.


**ZTH-VAV** Is replaced by the new ZTH.


**ZTH-GEN V2.xx / V3.xx / V4.xx** Is replaced by the new ZTH.


## Version overview

**V 2.01** Release of the ZTH and ZIP function









# All-inclusive.



5-year warranty



On site around the globe



A complete range of products from one source



Tested quality



Short delivery times



Comprehensive support

## Headquarters

**BELIMO Holding AG**  
Brunnenbachstrasse 1  
CH-8340 Hinwil  
Tel. +41 43 843 61 11  
Fax +41 43 843 62 68  
info@belimo.ch  
www.belimo.com

## Subsidiaries, Representatives and Agencies

Albania  
Algeria  
Argentina  
Australia  
Austria  
Bahrain  
Belarus  
Belgium  
Bosnia  
Brazil  
Bulgaria

Cameroon  
Canada  
Central America  
Chile  
China  
Croatia  
Cyprus  
Czech Republic  
Denmark  
Egypt  
Estonia  
Finland  
France  
Georgia  
Germany  
Greece  
Great Britain  
Hong Kong  
Hungary  
Iceland  
India  
Indonesia  
Ireland  
Israel  
Italy

Japan  
Jordan  
Kazakhstan  
Korea  
Kuwait  
Latvia  
Lebanon  
Libya  
Lithuania  
Luxembourg  
Macedonia  
Malaysia  
Malta  
Mexico  
Moldova  
Montenegro  
Morocco  
Netherlands  
New Zealand  
Norway  
Oman  
Pakistan  
Philippines  
Poland  
Portugal

Qatar  
Romania  
Russia  
Saudi Arabia  
Serbia  
Singapore  
Slovakia  
Slovenia  
South Africa  
Spain  
Sri Lanka  
Sweden  
Switzerland  
Taiwan  
Thailand  
Tunisia  
Turkey  
United Arab Emirates  
United States of America  
Vietnam

Belimo worldwide: [www.belimo.com](http://www.belimo.com)

**BELIMO®**